



## Installation Guide Touch-Up Kit for Frontier Desert Deck

1. Deck must be clean and dry. Using the liquid adhesive, paint the area to be patched.

**Note:** Allow adhesive to turn clear before applying the patch.

2. Using water, mix powder into a thick paste.
3. For each cup of touch-up kit mixture, add 1 to 3 teaspoons of adhesive, as desired.
4. Apply patch. Allow to set briefly and trowel to desired pattern, feathering into the existing deck.
5. If patch is larger than 3 inches in diameter, cover with plastic. Plastic should be cut slightly larger than the patch and secured with loose sand on top of the plastic to hold in place. Smaller patches may be cured by wetting down with clean water periodically over the following 24 hours.

As this is a masonry product, used beyond our control, Stegmeier LLC can assume no responsibility for color match and durability.

\* For technical support call 1 800 382-5430

DOWNLOAD THE LATEST STEGMEIER APP, AVAILABLE FOR IOS AND ANDROID